

The **J-CLASS** collection

MAGISTER VERTICAL DOUBLE TOURBILLON

How to use your watch

THE POWER RESERVE

The power reserve of a watch corresponds to the period of time between two consecutive windings, during which it will run without being worn on the wrist. When the watch stops, manual winding is recommended (at least 50 turns of the crown) to give the watch a minimum of power reserve when putting it back on your wrist.



a. White power reserve:

Shows that the movement is fully wound.

b. Red & black power reserve:

The watch is still functional, but the reserve is reaching its limit.

c. Red power reserve:

The movement has no more reserve and it needs to be wound.


DAY & NIGHT MODE:



a. White dial: Day mode

a. White & black dial: Transition from day to night

c. Black dial: Night mode



WATCH SETTING

TWO-position crown

1. Neutral and winding position

Allows the user to manually wind their watch by turning the crown upwards.

2. Time setting position

Allows the user to set the time by turning the crown and turning the hands to the right time.



SPEAKE-MARIN

CAUTION

Every time you change the time, remember to put the crown back in position 1.

WARNING

Your watch is guaranteed water-resistant to 3 bars (30 m) provided the crown is placed back in position 1.