
The **ONE&TWO** collection OPENWORKED DUAL TIME LIME How to use your watch



UNDERSTAND THE DUAL TIME

1. "Local Time"


There is, in the centre, a 12 hours dial to display the local time (hours and minutes).

2. "Home Time"

The 24 hours dial, positioned at 9:00, is split in mint for the day and black for the night. It displays the "Home Time" hours only.

3. Retrograde Date

On a 31-day ring, the hand jumps day by day. At the end of the 31st day, the spring allows the hand to reposition itself on day 1.



WATCH SETTING

THREE-position crown

Kindly set always the "Home Time" first.

1. Neutral and winding position

Allows the user to manually wind their watch by turning the crown upwards.

2. Local time setting position

Allows the user to set the time by turning the crown downwards: hours.

3. "Home time" setting position

Allows the user to set the time by turning the crown downwards; hours and minutes.

4. The date setting

For shorter months (<31 days), or simply to set the date, use the pusher on the left of the case with the help of a stylus.



CAUTION

Every time you change the time, remember to put the crown back in position 1.

WARNING

Your watch is guaranteed water-resistant to 3 bars (30 m) provided the crown is placed back in position 1.