

RIPPLES Timepiece
SMA0 in-house calibre

How to use your watch

THREE-position crown

Setting the time

Gently pull the winder out to the 2nd position.

Turn the winder to set the hour and minute hands to the correct positions.

The second hand starts again when the winder is pushed back into its normal position.



0. Security position

Prevents water from seeping into the watch by a screwed crown.



1. Neutral and winding position

Allows the user to manually wind their watch by turning the crown upwards

2. Time setting position

Allows the user to set the time by turning the crown and turning the hands to the right time.



SPEAKE MARIN

CAUTION

Every time you change the time, remember to put the crown screwed back in position 0.

WARNING

Your watch is guaranteed water-resistant to 5 bars (50 m) provided the crown is screwed back in position 0.

NOTE: Setting the date does not affect the working of the watch. When the watch is working, the date changes gradually during the period between 9:00 pm and 3:00 am.