ART SERIES Collection - Unique Timepiece Promenade à New York - TimeForArt auction 2024

How to use your watch



WATCH SETTING

TWO-position crown

1. Neutral and winding position

Allows the user to manually wind their watch by turning the crown upwards.

2

2. Time setting position

Allows the user to set the time by turning the crown and turning the hands to the right time.

SPEAKE MARIN

CAUTION

Every time you change the time, remember to put the crown back in position 1.

WARNING

Your watch is guaranteed water-resistant to 3 bars (30 m) provided the crown is placed back in position 1.